

Connection: Speakers and Tuner Antenna

Speakers

For details, please refer to *Instruction manual chapter "Connecting the Speakers" (Pg. 6)*


NOTE:

- Match the speaker cable color to the speaker / receiver terminals as shown on the illustration.
- Match the speaker to the correct terminal on the receiver (example: left speaker to left speaker terminal on receiver)


- The color of the cable should be the same as that on the terminals.
- Connect the striped color cable to the "-" terminal (both speaker and receiver)

SPEAKER HOOKUP


Follow the illustration and instructions provided to hook up your speakers.



ANTENNA HOOKUP




Antenna and Speaker Wire Connection



Connection: Audio/Video components

Follow the diagram to connect audio or video components.

Connection described below is also applicable for any component having analog output (TV, Cable & Satellite boxes, CD recorder/player,)



Cables

To help you identify the cables used in audio-video, illustrations are provided below for your easy reference.

RCA Audio cable (Analog)	Composite Video Cable (Usually yellow)	S-Video cable	Optical Cable (Digital)	Coaxial Cable (75Ω / Digital)	SCART Cable
Not Included	1Piece	Not Included	Not Included	Not Included	1Piece

Connection: Satellite & Digital Connections

Connection described below is also applicable for any component having digital output (TV, Cable & Satellite boxes, MD, CD recorder/player)

NOTE:

- By default, SAT is set to use analog input.
- After the connections are done, check the receiver and make sure it

is set to the appropriate digital/analog input by pressing the DIGITAL button on the remote control. The input will be displayed after the source name . (SAT/OPTI means SAT uses Optical Input)

- To change input connection, follow step 3 in "Digital Connection"
- If a COAXIAL cable is used to

connect SAT to the receiver, follow steps 3 in "Digital Connection" to select COAXIAL.

- S-Video connection provides better quality than composite connection.


If S-Video is used on your DVD receiver (SAT IN), MON OUT S-Video should also be used, otherwise, no picture will be displayed on TV.

Follow the diagram to connect your Satellite box to receiver.

- A Connecting your Satellite**
 - 1 Connect the RCA Audio cable.
 - 2 Connect the video cable (composite or s-video)

- B Digital Connections**
 - To receive Dolby Digital format or any digital signal, either a coaxial or optical cable must be connected. Follow the steps below for digital connection.

- 1 Connect either the COAXIAL or OPTICAL cable (not included)
- 2 Select SAT
- 3 Press DIGITAL button several times on the remote control to select the input being used (analog, coaxial, or optical)



Connection:

Speaker Hook-Up Placement

- 1

Center Speaker:

Positioned on top or below the TV set.
- 2

Front Speaker:

Positioned on both sides of the TV with equal distances away from the TV.
- 3

Rear Speaker:


Positioned beside or slightly behind your favorite viewing position. The height should be a little above your ear level.
- NOTE:

For effective SURROUND effect, rear speakers need to be located beside or behind your listening position.
- Advanced Set Up:

For more details on speaker placement, please refer to the manual chapter "Positioning Your Speaker" (Pg. 7)
- Subwoofer:

Positioned anywhere

For optimized performance, please follow the recommendations and illustration.



THOMSON

Thomson multimedia
46/47 quai A. Le Gallo
92648 Boulogne Cedex
FRANCE
RCS nanterre
B 322 019 464
TOCOM 55216410

THOMSON

Quick

Connect Guide

This guide will help you to set up your system through several illustrations.

DPL900VD

EN